

## Ans 2 Procedure

- 1) Plot the assumed design storm as a bar diagram with the unit hydrograph duration with the unit hydrograph duration as the time interval.
- 2) Subtract the infiltration losses to obtain effective precipitation.
- 3) Add the estimated base flow to get the anticipated flood hydrograph.