

Sec-3.

1. Write the problem and precaution steps to be taken.
a) Cast iron welding

Problems: ① Sealing Cracks

② Critical temperature.

③ Preheating

Precautions: keep it hot or keep it cool, but don't
change horses in the middle of the stream