

Ans 3 To obtain surface flow hydrograph,
base flow separated from total runoff.

Recurrence interval of flood - It denotes the
No of years in which a flood can be expected
once. It is the period of time between equaling
or exceeding of a specific flood. This is usually
denoted by a symbol T .

... e & ...